


WALL STUD

SAFETY BRACKET INSTRUCTIONS

PARTS ENCLOSED:

A (4) BRACKETS



B (2) SAFETY STRAPS



C (4) 1-1/2" WOOD SCREWS



D (4) 3/4" WOOD SCREWS




IMPORTANT: Tipping furniture can injure young children. Use of this safety bracket hardware is highly recommended. This safety hardware, when properly installed, can provide further protection against unexpected accidental tipping of furniture due to improper use.

Step 1

Attach a bracket to the wall board with the 1-1/2" wood screws provided:

- It is recommended that you locate a wall stud behind the furniture unit. If a wall stud is not used, a suitable "Hollow-Wall Anchor Bolt (not provided) should be used in lieu of the wall stud.
- Position the wall bracket on the stud about 1" below the top the furniture piece.
- Mark the position for the bracket placement on the wall and drill a pilot hole into the stud.
- Attach the bracket to the wallboard with the 1-1/2" screws provided.




Step 2

To attach a bracket to the Furniture Frame below the top with the short screws provided:

- Move the furniture piece temporarily to its final position to the wall.
- Mark the location of the bracket on the back of the furniture in relation to the previously mounted wall bracket.
- Move the furniture piece away from the wall mounted bracket and place the other bracket on the mark position on the back of the furniture piece.
- Drill a pilot hole as shown in the figure or into the back furniture frame.

Caution: Make sure you do not drill completely through the back of the furniture.


- Attach the bracket to the back of the furniture with the 3/4" screws provided.



Step 3

To Attach the safety strap:

- Move the furniture back to its final position.
- Thread the safety strap through both of the mounted brackets as shown in the illustration.
- Tighten the strap until snug.
- Do not over tighten.



Important: Make sure the brackets are firmly attached to the wall stud and furniture frame and the safety strap is snug.

Warning: This product is not to be a substitute for proper parental supervision which is the only proper deterrent to prevent improper use of this unit. The manufacturer assumes no liability for improper installation or excessive loads placed on the safety straps, bracket or mounting screws. This hardware will not insure against tipping.


Note: For taller or heavier pieces of furniture, two safety brackets may be installed.

1532 S. WASHINGTON AVE, PISCATAWAY, NJ 08854,
E-mail: info@evolurbaby.com
www.evolurbaby.com

INSTRUCTIONS POUR LA POSE DES FIXATIONS SUR MONTANTS DE CLOISONS

PIÈCES INCLUSES :

A (4) FIXATIONS



B (2) ATTACHES DE SÉCURITÉ



C (4) VIS À BOIS DE 1 1/2 PO



D (4) VIS À BOIS DE 3/4 PO




IMPORTANT : En basculant, le meuble peut blesser de jeunes enfants. Par conséquent, l'utilisation de ces fixations est fortement recommandée. Lorsqu'elles sont installées correctement, les fixations peuvent contribuer à empêcher le meuble de basculer accidentellement s'il est mal utilisé.

Étape 1

Poser une fixation au mur ou à la cloison avec les vis à bois de 1 1/2 po fournies :


- Il est préférable de trouver un des montants de la cloison derrière le meuble pour poser la fixation. S'il n'y a pas de montant, utiliser des boulons d'ancrage pour mur creux (non compris).
- Placer la fixation contre le montant, environ 2,5 cm (1 po) plus bas que le dessus du meuble.
- Marquer l'emplacement de la fixation sur le mur et percer un avant-trou dans le montant.
- Poser la fixation avec les vis de 1 1/2 po fournies.



Étape 2

Poser une fixation à l'arrière du meuble, sur le bâti, avec les petites vis fournies :


- Placer temporairement le meuble dans sa position définitive contre le mur.
 - Marquer l'emplacement de la fixation à l'arrière du meuble par rapport à celle déjà fixée au mur.
 - Éloigner le meuble du mur et placer la fixation à l'endroit marqué à l'arrière du meuble.
 - Percer un avant-trou comme l'indique l'illustration, à l'arrière du meuble dans le bâti.
- ATTENTION :** S'assurer en perçant de ne pas traverser complètement l'arrière du meuble.
- Poser la fixation à l'arrière du meuble avec les vis de 3/4 po fournies.



Étape 3

Poser les attaches de sécurité :

- Replacer le meuble à sa position définitive.
- Passer une attache dans les deux fixations — sur le mur et à l'arrière du meuble — comme le montre l'illustration.
- Serrer l'attache jusqu'à ce qu'elle n'offre plus aucun jeu.
- Ne pas trop serrer.



Important : Vérifier la solidité des fixations, au mur et à l'arrière du meuble, et s'assurer que l'attache est assez serrée.

Mise en garde : Ce produit ne doit pas remplacer une surveillance adéquate des parents, seule façon d'éviter que le meuble soit mal utilisé. Le fabricant ne peut être tenu responsable en cas d'installation inadéquate ou si une charge excessive est placée sur les attaches, les fixations ou les vis de montage. Ces pièces de quincaillerie ne peuvent totalement garantir la stabilité du meuble.

Remarque : Pour un meuble plus grand ou plus lourd, deux fixations peuvent être installées.

1532 S. WASHINGTON AVE, PISCATAWAY, NJ 08854,
E-mail: info@evolurbaby.com
www.evolurbaby.com



1532, S. Washington Avenue
Piscataway, NJ 08854
E-mail: info@evolurbaby.com

www.evolurbaby.com

Follow us on



to get your nursery featured on our social media.

Enter our monthly giveaway!

Simply scan the QRcode to register.



Chat with us!

For any questions or concerns or feedback.

